


SCHEDA TECNICA



SERRATURA INFILARE BORDO TONDO VIRO



Art.	Entrata	Larghezza della cassa	Dimensioni del catenaccio	Corsa delle mandate	Mandate
N.	mm E	mm A	mm B x D	mm C	N.
7435.20.1	20	35	40 x 8,5	14	1
7435.25.1	25	40	40 x 8,5	14	1
7435.30.1	30	45	40 x 8,5	14	1
7435.35.1	35	61	47 x 10	20	2
7435.40.1	40	66	47 x 10	20	2
7435.45.1	45	71	47 x 10	20	2
7435.50.1	50	76	47 x 10	20	2
7435.60.1	60	86	47 x 10	20	2
7435.70.1	70	96	47 x 10	20	2