




## Cremonese AP 25 – AP 50, con serratura

Cremonese costante e variabile, Entrata 25 – 50 mm



Cremonese AP 25 GV – AP 50 GV

### Cremonese AP 25 GK – AP 50 GK

Descrizione				Co
<b>Cremonese AP 25 GK, con serratura</b>				
<b>Entrata 25, Cremonese costante</b>				
HBB	Front.	G		PC
1851-2100	1940	980		3
2101-2350	2190	980		4
<b>Cremonese AP 30 GK, con serratura</b>				
<b>Entrata 30, Cremonese costante</b>				
HBB	Front.	G		PC
1851-2100	1940	980		3
2101-2350	2190	980		4
<b>Cremonese AP 35 GK, con serratura</b>				
<b>Entrata 35, Cremonese costante</b>				
HBB	Front.	G		PC
1851-2100	1940	980		3
2101-2350	2190	980		4
<b>Cremonese AP 40 GK, con serratura</b>				
<b>Entrata 40, Cremonese costante</b>				
HBB	Front.	G		PC
1851-2100	1940	980		3
2101-2350	2190	980		4
<b>Cremonese AP 45 GK, con serratura</b>				
<b>Entrata 45, Cremonese costante</b>				
HBB	Front.	G		PC
1851-2100	1940	980		3
2101-2350	2190	980		4
<b>Cremonese AP 50 GK, con serratura</b>				
<b>Entrata 50, Cremonese costante</b>				
HBB	Front.	G		PC
1851-2100	1940	980		3
2101-2350	2190	980		4

### Cremonese AP 25 GV – AP 50 GV

Descrizione				Co
<b>Cremonese AP 25 GV, con serratura</b>				
<b>Entrata 25, Cremonese variabile</b>				
HBB	Front.	GV		PC
951-1450	1130	475- 725		1
1451-1950	1630	725- 975		2
1951-2450	2130	975-1225		3
<b>Cremonese AP 30 GV, con serratura</b>				
<b>Entrata 30, Cremonese variabile</b>				
HBB	Front.	GV		PC
951-1450	1130	475- 725		1
1451-1950	1630	725- 975		2
1951-2450	2130	975-1225		3
<b>Cremonese AP 35 GV, con serratura</b>				
<b>Entrata 35, Cremonese variabile</b>				
HBB	Front.	GV		PC
951-1450	1130	475- 725		1
1451-1950	1630	725- 975		2
1951-2450	2130	975-1225		3
<b>Cremonese AP 40 GV, con serratura</b>				
<b>Entrata 40, Cremonese variabile</b>				
HBB	Front.	GV		PC
951-1450	1130	475- 725		1
1451-1950	1630	725- 975		2
1951-2450	2130	975-1225		3
<b>Cremonese AP 45 GV, con serratura</b>				
<b>Entrata 45, Cremonese variabile</b>				
HBB	Front.	GV		PC
951-1450	1130	475- 725		1